

# BlackBerry Battery Power Saving Tips

Dear Blackberry Customer,

Reliance Communications is privileged to serve you as one of our prestigious customers.

We intend to provide you the best of our services & enhance your experience of using Reliance Blackberry services.

This document has been prepared with a view to update you on some very useful tips that can help you enhance the usage capacity of your Blackberry handset battery.

We request you to refer these useful settings for your Blackberry handheld in order to minimize the consumption of handheld battery.

• <b>Charging your Handheld</b>
• <b>Media Related</b>
• <b>Browsing Related</b>
• <b>Screen/Keyboard Related</b>
• <b>Network Connections Related</b>
• <b>Power saving by using Shortcuts</b>
• <b>Effective use of Camera</b>
• <b>Applications Related</b>
• <b>Useful settings for Indicators</b>

For any further assistance, please feel free to call us on 022-30336363 or write in to us on [customercare.blackberry@relianceada.com](mailto:customercare.blackberry@relianceada.com)

Assuring you the best of our services always.

Warm Regards

Mr. Anurag Parashar  
President Corporate and Wireless  
Customer Service  
Reliance Communications Ltd.

## **Charging your Handheld** **(Top)**

- Charge your BlackBerry® smartphone as much as possible
- Use wall chargers as the preferred charging method

## **Media Related** **(Top)**

- Always keep the volume as minimum as possible
- Prefer to listen the music through headphone rather than on speaker
- Load media using the BlackBerry Desktop Manager (Avoids resizing)
- Turn off equalizer settings (Media > Options)

## **Browsing Related** **(Top)**

- Prefer to visit mobile version of websites wherever applicable
- Turn Repeat Animations to a lower setting (Browser > Options > General Properties)
- Close browser when finished using (Close with ESC key, not red End key)

## **Screen/Keyboard Related** **(Top)**

- Reduce Backlight Timeout (Options > Screen/Keyboard)
- Reduce Backlight Brightness (Options > Screen/Keyboard)
- Holster Smartphone (Turns off LCD automatically)
- Set Audible Roll to mute (Options > Screen/Keyboard)
- Keep the Key Tone Off (Options > Screen/Keyboard)
- Use a sleeve when storing the smartphone in a pocket

## **Network Connections Related** **(Top)**

- Turn off unused connections when not in use, i.e. GPS, Wi-Fi®, Bluetooth®
- Use Auto On/Off
- Use single mode only (1XEV, 2G only, 3G only)

### **Power saving by using Shortcuts** **(Top)**

- Use shortcuts instead of activating Java menus (Browser > Options > Browser Configuration)

### **Effective use of Camera** **(Top)**

- Turn off flash (Camera – Options)
- Set picture size to Small (Camera – Options)
- Set Color Effect to Normal (Camera – Options)
- Set Picture Quality to Normal (Camera – Options)

### **Applications Related** **(Top)**

- When exiting, be sure to close the app, not leave it running in the background (close with ESC key, not red End key)
- Log out of third-party applications when they are not needed (Instant Messaging, etc.)

### **Useful settings for Indicators** **(Top)**

- Set Audible notification to Off (Profiles)
- Turn off coverage LED (Profiles)